E KR108





Introduction

This is a low cost and high performance proximity reader for reading ID code from EM4100 or compatible read-only tags. It features an extended reading range up to 40-60 cm. It is ideally suited to be applied in automatic parking system, personal identification, access control and production control systems etc.

Features

- High sensitivity and reliable performance;
- Built-in transceiver antenna for max. performance;
- Maximum effective distance up to 40-60cm
- Less than 100ms decoding time;
- Low power dissipation with single power supply;
- Built-in buzzer;



Specification

| Power Requirements | Linear regulated 12VDC at 300mA typical, 500mA max. |
|-------------------------|---|
| Interface | Wiegand 26 bit |
| Max. Read Range | 40-60cm (using special 125Khz long range card) |
| Frequency | 125Khz typical / EM4100 or compatible |
| RFID card requirement | High Q 125K long range Read only card |
| Audio/visual Indication | Buzzer |
| Operating Temp. | -10°C - 70°C |
| Dimension | 240 X 235 X 35 (mm) |

Interface Description

| Color | Reader wires Description |
|-------|--------------------------|
| Red | +12VDC To power supply |
| Black | Ground To power supply |
| Green | Data 0 |
| White | Data 1 |

Protocol - Wiegand 26bit

Wiegand26 format

| P0 12 bits | 12 bits | P1 | |
|------------|---------|----|--|
|------------|---------|----|--|

PO - even parity for first 12 bits, P1 - odd parity for second

12 bits

Trouble shooting

When powered up, the reader takes a self-test to ensure the best reading performance with the buzzer beeping continually. When the self-test ends, the buzzer will give out a long beep and enter the normal working mode.

If the buzzer continue beeping without stop for a long time, Pls turn off the power and check out the environment and power supply to ensure locating the reader in a good working condition. In case of problems the following procedure should be followed:

Failure to finish self-test with the buzzer beeping continually or with a short reading distance.

- 1. check the power input connections making sure that they are not reversed
- 2. check the power supply complying with the specifications
- 3. change another brand power supply
- 4. if the supply has a current limit, set this to > 500 mA
- 5. make sure to install the reader in a environment without large area conductors nearby or mounting on a conductive surface. In self-test state, do not apply any tags in the reader functional area;
- 6. change to another location or angle to improve the reading range performance

Power supply requirement:

Linear regulated type external DC power supply

Voltage Output: + 12V DC +/- 5% at 2A typical

