



LOCK 1600

Customer signature protection hardware key for Héphaïs 1600

LOCK 1600 is a Customer signature protection key hardware for Héphaïs 1600 and Héphaïs 1600NE. This reference allows in association with the downloading software TéléHéphaïs 1600, to upload/download the panel with your own signed protection key.

From a standard, non signed, Héphaïs 1600 panel, the LOCK 1600 solution, can sign, lock and protect all your system from unrecognized user. Securing the Database of your project and the panel.

LOCK-1600 reference is available in the format of a USB key containing your own and unique id code.

Once a configuration or commissioning is undertaken with your personal LOCK 1600 USB key (download). Your system database and the Héphaïs 1600 panel will be then locked for download/upload unless you are using dedicated LOCK-1600 USB key



Main characteristics

- 1 Very easy to use and associate
- 2 Complete protection
- 3 Unique ID available in 1 or more USB keys
- 4 Secure your projects
- 5 **Save your maintenance contracts**
- 6 One year licence duration renewable



